



Magic Sleek™ Product Instructions

Magic Sleek™ Emergency Repair How to Use It

- Make sure hair is damp
- Pour contents of Emergency Repair into a bowl
- Refill the empty vial with water and add to bowl
- Mix until combined
- Apply to ends and mid-length of damp hair and comb through
- Leave on for a minimum of 20 minutes (longer if possible)

- Rinse and style (use cold water for extra shine)

Magic Sleek™ Acai Oil

How to Use It

- Work a small amount of oil between palms
- Apply to hair from ends to mid-length, avoiding the roots

- Focus on most damaged areas

Magic Sleek™ Pro Titanium Iron

How to Use It

- Plug into the correct power supply. Our flat iron has universal voltage, which adapts to 100-240 V (50/60 HZ).
- Hold the 'on/off' button for 3 seconds. Within 30-50 seconds, the heating plates will reach the default temperature.
- Press the '+/-' button to adjust the temperature according to your hair type and tolerance to heat.
- After reaching the desired temperature, the flat iron auto-locks. Press 'on/off' button twice to unlock. Digital display will appear white when the auto-lock feature is on and blue when it's off.
- Hold the 'on/off' button for 3 seconds to shut the flat iron off. Unplug the cord and wait for the flat iron to cool down.

Magic Sleek™ Styling Clips *Limited Edition*

How to Use It

- For damp hair, use lower arm to create vertical sections. Clip, dry, and style!
- For dry hair, use lower arm to create horizontal sections. Clip, dry, and style!
- Apply Magic Sleek™ Acai Oil to lock in shine and finish your look!